



CONSTRUCTION:

Bright-polished chrome-plated zamak.

INSTALLATION:

Mark wall using the paper holder as a template. Attach paper holder with two #14 x 1" (25mm) slotted pan head screws provided. Wood blocking is preferable behind all wall surfaces.

NOTE:

If wood blocking is not available, the following optional fasteners are suggested:

- Tile/Masonry - Plastic or lead anchors
- Plaster/Drywall -Toggle bolts

Surface-Mounted Single Toilet Tissue Holder shall be Model 815 of Gamco Commercial Restroom Accessories, One Gamco Place, Durant, OK, 74701-1910